

Fractionalize Primary rate

ISDN PRI Trunks: Procedure for ISDN PRI fractional support.	
Hardware:	SV8100 CPU [All versions]
Section:	ISDN PRI Trunks
Sub-section:	Procedure for Fractional Support
Description	Frequently, it may be desirable to install less than the maximum possible 30 ISDN channels. This may be due to a need to maximize port use or the customer's modest trunk requirements.
Result	<p>At the time of this writing, Fractional Mode may only be carried out via WebPro. This scenario will likely change with future releases of PCPro.</p> <ol style="list-style-type: none">1. Connect via WebPro.2. Enable PRT fractional support (PRG 10-39-01).3. Click 'Apply' and logout.4. Insert PRI blade.5. Connect via WebPro.6. Assign number of channels (PRG 10-03-21).7. Reset the PRI by removing and reinserting the blade.