

**Auckland:** Telco House  
Level 3, 16 kingston St,  
PO Box 91521, Auckland,  
New Zealand 1010.  
Tel +649 356 8490 Fax +649 356 8499

**Wellington:** Level 4,  
5-7 Willeston Street,. PO Box 2377  
Tel +644 472 2961 Fax +644 472 2966

Author : Paul Warner  
Document Number: KTS TIB 0065 Release Number:2  
DID : +649 357 3403  
Date : October 04. 2010  
Email : [paul.warner@necbs.co.nz](mailto:paul.warner@necbs.co.nz)  
Number of pages : 2 including this page

---

## TECHNICAL NOTE: SV8100: CONFERENCE GROUPS SETUP

---

Changers from Issue 1 are in **RED**

An undocumented featured appeared in one SV8100 software releases called Conference Groups. This allows a site to have up to four dial in Conference Groups setup with PIN access. As no mention has ever been made of this feature in the R1.00 ~ R4.00 release SIBs, Feature or Program Manuals. This TIB is to help techs set this service feature .

With this feature there is no need for a conference bridge card for simple conference setup.

1 PRG 11.19

**System Data**  
**11-19 : Conference Group Pilot Numbers**

Conference Group	Pilot
1	<input type="text" value="401"/>
2	<input type="text" value="402"/>
3	<input type="text"/>
4	<input type="text"/>

Assign an extension number that is unique within 11-02, 11-04, 11-06, 11-07, 11-08, 11-17 and 11-19. It must match the system numbering plan as setup in 11-01 and 11-20. Valid extension numbers are 1xx, 2xx, 3xxx, 4xx, 5xx, 6xx, 7xx, 8xx.

Add pilot numbers for the Conference groups. These can be any free number in the system.

2. PRG 20.35

Conference Group	Name	Password	Maximum Participants	Maximum Conference Duration	Ending Conference Alert Tone Time
1	Conf 1	1111	8	7200	300
2	Conf 2	2222	8	7200	300
3	Conf 3	3333	8	7200	300
4	Conf 4	4444	8	7200	300

- 20.35.01 : Conference Group Name .
  - 20.35.02: Default password for Conference Group .
  - 20.35.03: Number of conference participants (0~32) .
  - 20.35.04: Maximum conference duration before conference is force disconnected. 7200 seconds = 120 minutes.
  - 20.35.05 Ending conference alert tone. This sounds off 300 seconds before the conference is due to end. 300 seconds is 5 minutes.
- The above are defaults and can be change d to suit.

For voice prompts at conference login a VM21 and InMail card must be installed in the system.. Without the InMail CF no prompts are heard.

**Access**

Locally: Dial the conference pilot number, when you hear the prompt to enter your password and you will access the conference. A tone is sounded when you enter the conference. If you enter the wrong PIN you will hear a tone and will be disconnected.

Externally: Dial via the VRS AA to access the Conference group using single digit dialing in PRG 25.06. (set a DID translation entry to go to the Conference group, DIL entry to Conference group pilot number..

**Limitations:**

- Conference groups cannot be accessed via InMail or UM8000 AA.
- Station transfer to Conference Group pilot will not work .

The Conference Group passwords can be changed with WebPro login admin1 or normal tech login.